

Englisch

How to flash the image to the micro SD card:

1) Download

<http://releases.libreelec.tv/LibreELEC.USB-SD.Creator.Win32.exe>

or

<https://downloads.sourceforge.net/project/win32diskimager/Archive/win32diskimager-1.0.0-install.exe>

2) Start the application

3) Select local image file (Select file) and use *.img (500MB)

4) Write the image

5) Disconnect the power supply, insert card/drive, push reset button and connect the power while holding the button. Wait until LibreELEC logo appears and release the button.